

Ceiling Fan Assembly



Parts




Wireless Receiver



Base Attachment

Fan speed (0 - 1 - 2 - 3) and light (On - Off) can be controlled by wireless remote (Transmitter and Receiver).



Assembling



Assembled