
Repair Bicycle



Valve Type






Rear Wheel Removed

Detaching Tire







Air Bubbles from Tube Punctured



Bottom Surface of Tire where Tube Liner Protector Sits



Tube Liner Protectors & New Tubes