Repair Tiller

Leaking gasoline started because fuel hose deteriorated.



Leaking Gasoline through Black Deteriorated Fuel Hose



Cut (See Right) & Detach (See Left)



Connected between Old & New Hose by Epoxy Putty



Done

Applying epoxy putty eases the fuel hose replacement so much.